

To Restore f-POD Ultra Software

1: Remove flightcase top cover

2: Open Control panel

3: Locate plastic bag and remove USB Memory Stick

(This holds a backup of the factory settings)

4: Close Control panel

5: Remove USB Socket cap

6: Switch control switch to ON INT

7: Watch screen, when 'American Megatrends' plug USB memory stick IMMEDIATELY

8: Wait as the PC loads windows and f-POD software

9: Enter PIN code as normal

10: PC should now be restored.

11: Return USB Memory stick to its plastic bag inside the control panel

12: Lock the control panel and secure the external battery cable with a tie wrap

13: Re fit Flightcase top.